


# SDB HD7-BELT



# SDB HD7-BELT



# SDB HD7-BELT

The SILENT DISCO BOX HD7-BELT is a wireless receiver. It works with all the other Silent Disco Box 3 channel products. This product makes it possible to connect your own headphone through the 3.5mm mini-jack connector. Or you can use it to receive signal and connect this to AV equipment like home audio systems. The receiver has a build-in rechargeable battery and can be used up to 10 hours between charges. It takes only 3 hours to fully charge. The logo changes color when you change the channel. The product is very lightweight and the belt bucket makes it easy to wear.

## Quick Start

1. Press and hold the power on/off button for two seconds to turn the receiver on.
2. Slide the channel button to choose the channel of the transmitter.
3. Plug your earphones in through the headphone output.
4. Adjust the volume.
5. Press and hold the power on/off button for two seconds to turn the receiver off until the LED light of the logo display is off.

## Specifications

Wireless Stereo transmitter UHF/RF system FM modulation.

Frequencies; 863.100Mhz, 863.800Mhz, 864.950Mhz.

Frequency response; 30-20000 Hz

Power supply; build-in rechargeable battery

Headphone impedance; 32 ohm